

## Tools for Working on Bearings

Made in USA by  
Sonny's Bike Tools

**NEW ITEMS!**



### Bottom Bracket Tools

<b>Part Number</b>	<b>Model</b>	<b>Description</b>
BRT-003	BB86/92 Tool	Tool for the Removal and Install of all BB86 and BB92 systems.
BBT-001	X-Drive Cup Tool	Tool for removal and install of any FSA, Shimano, SRAM, Truvative or Enduro Style Outboard Cups
BBT-001/B	Shimano Fixing Bolt Tool	Tool for removal and install of crank fixing bolt
BRT-001	X-Drive BB Tool Set	Tool for removal and install of bearings into any standard outboard cups
CT-006	Campagnolo Ultra Torque Bearing Removal Tool	Tool for removing the bearing from the crank spindle on Campagnolo Cranks
CT-007	Campagnolo Ultra Torque Bearing Install Pilots	These Pilots work with the BRT-005 (Hub Press) to press new bearings onto the Ultra Torque Cranks
CT-008	Cannondale Hollogram crank removal tool	This tool allows you to easily remove the Cannondale Hollowgram crank arms without damage
CT-001	Cannondale Crank Spider	This tool allows you to swap out the chain rings on Cannondale cranks by removing the spider
CT-002	Cap Pin FSA, Cann, Zipp	This tool allows you to remove the cap pin on the FSA, Cannondale and Zipp Crank Sets

CT-003	Rotor 30 mm Spider Tool	This tool allows you to remove and replace the lockring for either 30 mm OR compact spider new style
CT-003/2	Rotor Compact Spider Tool	This tool allows you to remove and replace the lockring for the spider on the Rotor Standard 30 mm crankset

TK TorqTite Wrench	TT wrench for BB86/92, PF30
--------------------	-----------------------------

### **BB30 Tools**

<b><u>Part Number</u></b>	<b><u>Model</u></b>	<b><u>Description</u></b>
BRT-002	BB30 Bottom Bracket Tool	This tool allows you to safely remove and install the 6806 Bearings into any PF30 or BB30 Bottom Bracket

BBT-003	BB30 Cup Removal Tool	This tool is for the removal and install of BB30 cups. It comes with an alignment shaft as well
---------	-----------------------	---

### **BB90 Tool**

<b><u>Part Number</u></b>	<b><u>Model</u></b>	<b><u>Description</u></b>
BBT-006	BB90 Bottom Bracket Tool	This tool works in conjunction with the BBT-005 to press bearings into the BB90 Bottom Brackets. Will work with Shimano and SRAM style bearings from Enduro

### **Hub and Suspension Pivot Tools**

<b><u>Part Number</u></b>	<b><u>Model</u></b>	<b><u>Description</u></b>
BBT-100	Blind hole Puller Set	This Tool set allows you to pull and bearings that are pressed into a housing as found in all hubs and pivots. Work with any bearing with an inside diameter between 8-40mm.

BRT-005	Hub Press	Tool set for pressing bearings into Hubs, Pivots or some BB's. Contains 12 bushing to fit all of the major size bearings used in hubs and pivots.
---------	-----------	---

LHT-001	Lefty Hub Pin Tool for	Pin Tool for Remove/Replace Lefty Cap on Cannondale Lefty Hubs
BBT-105	V-Type Bearings puller	Small Bearing Puller Tool 8-25 mm
NBT-001	Needle Bearing Tool	Removes and Installs shock eye needle bearings
NBT-002	Needle bearing Tool	Guides for Install

### **Parts for Tools**

<b>Part Number</b>	<b>Model</b>	<b>Description</b>
TK HT T-Handle	Handle for BRT-005	
TK HT Rod	Rod Only For BRT-005 Handle	
TK PT 003	Pilot Bushing for BRT-001	
TK PT 005	Bushing Truvative	
TK PT 006	Split Collet for BRT-001	
TK PT 007	Support washer/ BRT-001	
TK PT 008	Threaded Cup/BRT-001	
TK PT 009	Collet for BRT-006	Split Collet for BB 86/92 Toolk
TK PT 030	Collet for BRT-002	Split Collet for BB30/PF30 Tool

TK HT 6000 Inner	Guide for 6000 bearing	Inner Hub Press Tool Guide
TK HT 6000 Outer	Guide for 6000 bearing	Outer Hub Press Tool Guide
TK HT 6001 Inner	Guide for 6001 bearing	Inner Hub Press Tool Guide
TK HT 6001 Outer	Guide for 6001 bearing	Outer Hub Press Tool Guide
TK HT 608 Inner	Guide for 608 bearing	Inner Hub Press Tool Guide
TK HT 608 Outer	Guide for 608 bearing	Outer Hub Press Tool Guide
TK HT 6704 Outer	Guide for 6704 bearing	Outer Hub Press Tool Guide
TK HT 6800 Inner	Guide for 6800 bearing	Inner Hub Press Tool Guide
TK HT 6801 Inner	Guide for 6801 bearing	Inner Hub Press Tool Guide
TK HT 6801 Outer	Guide for 6801 bearing	Outer Hub Press Tool Guide
TK HT 6802 Inner	Guide for 6802 bearing	Inner Hub Press Tool Guide
TK HT 6802 Outer	Guide for 6802 bearing	Outer Hub Press Tool Guide
TK HT 6803 Inner	Guide for 6803 bearing	Inner Hub Press Tool Guide
TK HT 6803 Outer	Guide for 6803 bearing	Outer Hub Press Tool Guide
TK HT 6804 Inner	Guide for 6804 bearing	Inner Hub Press Tool Guide
TK HT 6804 Outer	Guide for 6804 bearing	Outer Hub Press Tool Guide
TK HT 6805 Inner	Guide for 6805 bearing	Inner Hub Press Tool Guide
TK HT 6805 Outer	Guide for 6805 bearing	Outer Hub Press Tool Guide
TK HT 6806 Inner	Guide for 6806 bearing	Inner Hub Press Tool Guide

TK HT 6900 Inner	Guide for 6900 bearing	Inner Hub Press Tool Guide
TK HT 6901 Inner	Guide for 6901 bearing	Inner Hub Press Tool Guide
TK HT 6901 Outer	Guide for 6901 bearing	Outer Hub Press Tool Guide
TK HT 6902 Inner	Guide for 6902 bearing	Inner Hub Press Tool Guide
TK HT 6902 Outer	Guide for 6902 bearing	Outer Hub Press Tool Guide
TK HT 6903 Inner	Guide for 6903 bearing	Inner Hub Press Tool Guide
TK HT 6903 Outer	Guide for 6903 bearing	Outer Hub Press Tool Guide
TK HT MR 1526 In	Guide for 1526 bearing	Inner Hub Press Tool Guide
TK HT MR 1526 Out	Guide for 1526 bearing	Outer Hub Press Tool Guide
TK HT MR1728 In	Guide for 1728 bearing	Inner Hub Press Tool Guide
TK HT MR1728 Out	Guide for 1728 bearing	Outer Hub Press Tool Guide
TK HT R6 Inner	Guide for R6 bearing	Inner Hub Press Tool Guide
TK HT R6 Outer	Guide for R6 bearing	Outer Hub Press Tool Guide
TK HT MR 2437 In	Guide for 2437 bearing	Will Install Both 6805 and MR 2437 Bearings

TK HT Multi-I	All Inner Guides for Hub Tool	
TK HT Multi- Outer	All Outer Guides	

TK puller 8-10mm	Individual Replacement Puller for 8-10 mm
TK puller 10-12mm	Individual Replacement Puller for 10-12 mm
TK puller 12-14mm	Individual Replacement Puller for 12-24 mm
TK puller 15-17mm	Individual Replacement Puller for 15-17 mm
TK puller 20-24mm	Individual Replacement Puller for 20-24 mm
TK puller 25-29mm	Individual Replacement Puller for 25-29 mm
TK puller 30-32mm	Individual Replacement Puller for 30-32 mm

Outer Guide



Inner Guide



NEW CT-003/2 For new Rotor 30 mm spider



CT-003 with CT-003/2



NEW CT-008 For Cannondale Hologram Crank Removal



BRT-003 (BB86/92 Tool)

